SYNTHIAM

synthiam.com

Use Arduino for Wheel Encoder Counter

Have your Arduino count motor encoder rotations. Connect the Arduino to your EZ-B UART #0 port to send the encoder counts.

Last Updated: 5/26/2016

Connect The Wires

There are two sets of wires which will need to be connected:

1. The Arduino to the encoder
2. The Arduino to the EZ-B

Encoder

Connect the encoder wires to your Arduino pins 2 and 3. These pins are interrupt pins. The code will count the number of changes between HIGH and LOW state of these pins.

- pin 2: Encoder #1
- pin 3: Encoder #2

EZ-B

Connect the Arduino's TX and RX ports to the UART #0 of the EZ-B. Consult the ez-b datasheet to locate the UART #0 port.

- Connect EZB UART 0 TX to ARDUINO RX
- Connect EZB UART 0 RX to ARDUINO TX
- Connect Arduino GND to EZ-B GND

Program Arduino

Here is the program which you will upload to your Arduino. The program has 2 interrupt counters for the pins connected to the encoders. The main program will loop until the letter 'a' i received from the EZ-B over the UART. Once the 'a' is received, the Arduino will transmit 2 bytes, which is are the two encoder values, respectively. Once the data is transmitted, the count of the 2 bytes is reset.
Resetting the values on each query will make it much easier in EZ-Builder to identify what wheel is spinning quicker/slower.
Arduino Code:

```

// just reading the encoder, nothing else.
int encoderValue_A = 0;
int encoderValue_B = 0;
void setup() {
Serial.begin(9600);
pinMode(2, INPUT);
pinMode(3, INPUT);
attachInterrupt(digitalPinToInterrupt(2), countA, FALLING);
attachInterrupt(digitalPinToInterrupt(3), countB, FALLING);
}
void loop() {
// if there is data to read, read it
if (Serial.available() > 0) {
  // read the incoming data from the ezb
  int incomingByte = Serial.read();

  // command 'a' means transmit the current values and reset the counters
  if (incomingByte == 'a') {

    // send the values
    Serial.write(encoderValue_A);
    Serial.write(encoderValue_B);

    // reset the values
    encoderValue_A = 0;
    encoderValue_B = 0;
  }
}
void countA() {
encoderValue_A++;

}
void countB() {
encoderValue_B++;

}

```

EZ-Script Program

In EZ-Builder, add a new EZ-Script control.
This code will be pasted into the EZ-Script control. The code will loop and continue to request the interrupt counts of the encoders from the Arduino.
The values of the encoder are in the array $encoders[0] and $encoders[1]. You may use these two values globally within the project to identify what the encoder values are.
EZB Code

```

uartinit(0, 0, 9600)
:loop
# Send a request for data to the arduino
uartwrite(0, 0, "a")
# wait a bit for the data to be transmitted
sleep(50)
$dataAvail = UartAvailable(0, 0)
IF ($dataAvail != 2)
print("The arduino didn't send us anything. Exiting")
halt()
ELSE
UartReadBinary(0, 0, 2, $encoders)
print("Encoder A: " + $encoders[0])
print("Encoder B: " + $encoders[1])
ENDIF
sleep(100)
goto(loop)

```

Reference

This tutorial was inspired from this thread: https://www.ez-robot.com/Community/Forum/Thread?threadId=5603&page=3